
How to Apply the VRTX TLSO




1



PLACEMENT OF THE BACK PANEL

Place the back panel in the center of the back as low as possible.


2



PLACEMENT OF THE FRONT PANEL

Wrap around the front panel and attach the belt using the hook and loop. Ensure that the belt is secure.


3



CLIP THE STRAPS

Locate the straps and clip to the chest pad. Pull the strap to tighten.

4



ADJUST THE COMPRESSION

Slip your thumbs through the holes in the pull tabs. Pull away from your body until a comfortable level of compression is achieved. Reverse the steps to take off the brace.



