


How to Apply the VRTX CTLSO




1



PLACEMENT OF BACK PANELS

With the head in neutral position, center the back panel and collar back panel. Ensure the back of the collar panel is between the ears and upper shoulders.


2



PLACEMENT OF FRONT PANELS

Wrap around the front panel and attach the belt using the hook and loop. Ensure that the belt is secure.


3



TIGHTENING THE COLLAR STRAPS

While holding the front panel of the collar, attach the loop straps on each side. To tighten, peel back the loop straps one at a time, tighten and re-attach.


4



CLIPPING IN THE STRAPS

While holding the front panel, clip in both thoracic straps and pull to tighten.


5



ADJUSTING COMPRESSION

Slip your thumbs through the holes in the pull tabs. Pull away from your body until a comfortable level of compression is achieved.

6



CHECK THE FIT

Secure the pull tabs to the front of the brace.

TAKING OFF

Reverse steps to remove.

