




# HORIZON PRO 456 TLSO PATIENT APPLICATION

PRODUCT INFORMATION

HORIZON PRO 456 TLSO



HORIZON PRO 456 TLSO






## APPLYING THE BRACE

1. Place the pull-tabs on the belt 2 inches (5 cm) from the plastic in the back of the Horizon Pro 456 TLSO. Pull the ends of the belt away from each other ensuring that the belt is fully extended.

2. Put on the brace like a backpack.

3A. Place the back panel so that the bottom of the back panel is at or near the top of the buttocks.



3B. Wrap the brace around the abdomen, the right side overlapping the left. Ensure that the brace is snug. 3C. Slip your thumbs through the holes in the pull tabs. Pull directly away from your body until your arms are almost fully extended. This is maximum compression provided by the brace.

4A. Adjust the vertical height with the posterior adjustment panel. The yoke should sit at level C7 on patient.

4B. Pull and tighten the shoulder straps until properly fit.

4C. Fasten and tighten the chest buckle to draw the shoulder straps away from the armpits which may be more desirable for some patients.