


How to Apply the ALIGN ORTHOSIS TLSO




1



APPLYING THE BRACE

To apply the brace, place the back panel in the center of the back. Wrap the belt around the waist, ensuring the rigid axillary frame goes under the armpit. Attach the right arm of the belt to the anterior panel.


2



ENGAGE THE CHEST BUCKLE

Place the peg into the opening of the buckle. Squeeze together until click is felt to confirm buckle is engaged.


3



ENGAGE COMPRESSION

Slip your thumbs through the holes in the pull tabs. Pull away from your body until a comfortable level of compression is achieved.

4



BRACE REMOVAL

1. Disengage compression mechanism and place thumb tabs towards back of belt.
2. Disengage chest buckle.
3. Peel right side of belt away from anterior panel and remove.

